

P2-TR



AVIO/HELICOPTER



EXTERNAL CONNECTOR

A connector socket is fitted to the back of the unit allowing users to connect avio starting connectors to the unit.



TROLLEY SYSTEM

Easily move the booster to where it is needed using the trolley wheels and handle.

REVERSE POLARITY ALARM

This audible and visual alert informs professionals of incorrect terminal connections.

12-24V SWITCH

Easy to use switch allows the booster to be changed from 12V to 24V.

DIGITAL VOLTMETER

This display allows professionals to quickly see the voltage available and to test the alternator of a vehicle.

P2-TR-33

Model	Volts	Peak Amps (A)	Starting Amps (A)	# Of Batteries	Location of Fuse	Fuse (A)	Dimensions (cm)	Cable Diameter (mm ²)	Cable Reach (cm)	Unit Weight (KG)	Charger Voltage (V)	Charger Amps (A)	Vehicle Types
P2-TR-33	12/24	6400/3200	2560/1280	3	Clamp	500	36x16x42	50	205	37	230	3	 